


SERVICE MANUAL

Model **MR-G50J-SS-NZ**



Model name
indication
(Inside a door)

NZ.....New Zealand

CONTENTS

1. FEATURES	2
2. SPECIFICATIONS.....	3
3. WIRING DIAGRAM.....	5
4. OUTLINES AND DIMENSIONS.....	7
5. REFRIGERANT CIRCUIT.....	8
6. TROUBLESHOOTING	9
6-1 FUNCTION OF OPERATION PANEL	9
6-2 FLOWCHART OF SELF-CHECK.....	14
6-3 BLOCK DIAGRAM OF PRINTED CIRCUIT BOARD	17
6-4 AUTO ICE MAKER.....	17
6-5 FLOWCHART OF TROUBLE CRITERION.....	19
6-6 TROUBLE CRITERION OF MAIN PARTS.....	26
6-7 TEST POINT DIAGRAM OF FILTER BOARD.....	31
6-8 TEST POINT DIAGRAM OF CONTROL BOARD.....	32
7. NAMES OF THE PARTS.....	33
8. DISASSEMBLY INSTRUCTIONS.....	34
9. RoHS PARTS LIST.....	41

NOTE:

- RoHS compliant products have <G> mark on the spec name plate.

MR-G50J-NZ

1. Vegetable compartment

(1) Mechanism

Two LED lights are mounted on the back and bottom of the vegetable compartment. The LED (UV LED) emits 375nm light, which is the effective wavelength for biosynthesis of polyphenol. This revolutionary vegetable compartment stimulates self-defense function of vegetables and increases polyphenol by irradiating ultraviolet light to vegetables for a certain period of time.



* The lighting of LED is not controlled by opening or closing of the vegetable compartment door. Thus, the LED may not be lighted when the door is opened.

(2) Effect

Polyphenol in vegetables increased by 10% compared to the time of purchase, and the amount of retained polyphenol was 1.2 times more than that of the vegetables preserved in prior refrigerators without light radiation. (See graph)

Among different wavelength of light included in sunlight, lights of wavelength that "stimulates photosynthesis" and "stimulates polyphenol increase" are used in the vegetable compartment.

Rate of change in amount of polyphenol (Cress stored for three days)



2. " Auto Door Shut" function installed enable doors to be shut easily.

"Auto Door Shut" function automatically closes the door when its opened angle is less than 20 degrees.

3. Easy Access Vegetable room, Easy Access Freezer Room

The slide rollers enable smooth movement of vegetable and freezer rooms. Double rails allow the rooms to be pulled out completely, providing easy access to even the back of the rooms.

▼Slide rollers



SPECIFICATIONS
MR-G50J-NZ

Power supply		V,Hz	230V,50Hz
Total capacity		L	492 (R:264 F:82 V:97 I:12 S:37)
Dimensions (H x W x D)		mm (inches)	1798 x 745 x 699 (70-25/32 x 29-11/32 x 27-17/32)
Cabinet		Acrylic resin coated steel	
Food liner		ABS resin	
Insulation	Cabinet	Foamed polyurethane (Cyclopentane)	
	Freezer door	Foamed polyurethane (Cyclopentane)	
	Refrigerator door	Foamed polyurethane (Cyclopentane)	
Cooling system	Freezer	Forced air convection	
	Refrigerator	Forced air convection	
Evaporator		Fin and tube type	
Condenser		Cabinet, cabinet ceiling, sides, back and front flange	
Defrost system		Automatic heater defrost	
Drain		Automatic drainage, Forced evaporation method	
Temperature control system		Automatic control	
Refrigerator compartment room light		240V,10W (E12)	
Accessories	Free pocket (L)		2pcs.
	Free pocket (S)		2pcs.
	Bottle pocket (S)		1pc.
	Bottle pocket (L)		1pc.
	Tube stand		1pc.
	Height adjustable shelf		1pc.
	Three-way flexishelf		1pc.
	Two-way flexishelf		1pc.
	Small item case		2pcs.
	Free egg shelf		2pcs.
	Slide chilled case		1pc.
	Slide chilled case lid		1pc.
	Versa case		1pc.
	Aluminum tray (Versa case)		1pc.
	Water tank (With light-type bacteria removing filter)		1pc.
	Freezing case (upper)		1pc.
	Freezing case (lower)		1pc.
	Ice server		1pc.
	Sound proof mat		1pc.
	Ice storage bin		1pc.
	Vegetable case		1pc.
Vegetable stand		1pc.	
Sliding case (Vegetable case)		1pc.	
Drain pan		1pc.	
Toe grille		1pc.	
Weight	Unit	kg	99
	Shipping	kg	110
Capillary tube		mm	$\phi 1.6 \times \phi 0.63 \times 2680 / \phi 1.8 \times \phi 0.67 \times 2680$
Desiccant (molecular sieve)		g	9
Refrigerant filling capacity R600a		g	82
Refrigerating oil (Model)		g	187 (FREOL S10)


ELECTRICAL PARTS SPECIFICATIONS MR-G50J-NZ

Compressor		Model		ETI100E 13DAH	
		Power supply		230V,50Hz	
		Rated input	W	45/159 (1620/4800rps)	
		Starting current	A	2.0 (Current limiter)	
		Running current	A	0.63/2.19 (1620/4800rps)	
		Winding resistance (A.T.20°C)		9.27Ω	
Motor protector		Model		MM3-71CCV	
		Ambient temperature	°C	25	
		Time	Sec.	16 or less	
		Current	A	17.0	
Three-way valve		Model		NSCE001DC1	
		Type		4-phase stepping motor drive voltage DC12V	
Defrosting control	Defrosting timer	Model		Control board	
		Specification		Microcomputer	
	Freezer compartment	Defrost finish	°C	Thermistor 14±1.5	
		Thermal fuse	°C	70±2	
		Defrost heater		325Ω (230V,163W)	
Deodorizing function of defrost heater		Not Equipped			
Fan motor	Refrigerator	Model		UDQM002B3	
		Type		DC brushless motor	
		Input	W	2.4 (12V DC)	
		Revolution	rpm	1520 (12V DC)	
		Number of poles		10P	
	Machine Chamber	Model		UDQM004B3	
		Type		DC brushless motor	
		Input	W	1 (12V DC)	
		Revolution	rpm	1200 (12V DC)	
		Number of poles		10P	
Heater (Rating)		Water pipe heater		230V-8.0W	
		Rotational heater board		230V-8.0W	
		Divider heater (I/S)		230V-5.5W	
		Vegetable compartment heater 1		230V-9.0W	
		Vegetable compartment heater 2		230V-9.0W	
		Ice making tray heater		220V-10.0W	
Ice maker temperature		°C	-11.6		

Temperature control	Model		NTC thermistor										
			Freezer		Refrigerator		Versa		Slide chilled		Ice making		Vegetable
	Compressor		Motor damper						Heater				
	Dial position		ON	OFF	OPEN	SHUT	OPEN	SHUT	OPEN	SHUT	OPEN	SHUT	ON
HI	°C	-20.3	-24.1	-0.6	-1.8	-	-	-	-	-	-	2.3	3.5
MID	°C	-17.6	-21.4	1.6	0.4	-	-	-	-	-	-	3.2	4.5
LOW	°C	-14.9	-18.7	4.8	3.5	-	-	-	-	-	-	4.2	5.4
REFRIGERATOR	°C	-	-	-	-	4.4	2.4	-	-	1.2	-0.1	-	-
CHILLED	°C	-	-	-	-	1.8	-0.1	-1.0	-2.3	-	-	-	-
LOW (Soft freezing)	°C	-	-	-	-	-2.3	-4.0	-	-	-	-	-	-
MID (Soft freezing)	°C	-	-	-	-	-4.0	-5.9	-	-	-	-	-	-
HI (Soft freezing)	°C	-	-	-	-	-5.9	-7.7	-	-	-	-	-	-
FREEZER	°C	-	-	-	-	-17.1	-20.4	-	-	-	-	-	-
ICE MAKING	°C	-	-	-	-	-	-	-	-	-20.2	-23.1	-	-
ICE MAKING STOP	°C	-	-	-	-	-	-	-	-	-20.2	-23.1	-	-
CRYSTAL ICE MAKING	°C	-	-	-	-	-	-	-	-	-20.2	-23.1	-	-

MR-G50J-NZ

(SKELTON WIRING DIAGRAM)




* WHEN THE DOORS ARE CLOSED.

- I.THERMISTOR (Ice making compartment thermistor)
- V.THERMISTOR (Vegetable compartment thermistor)
- VERSA.THERMISTOR (Versa compartment thermistor)
- DEF.THERMISTOR (Defrost thermistor)
- ICE-TRAY THERMISTOR (Ice making tray thermistor)
- F.THERMISTOR (Freezer compartment thermistor)
- C.THERMISTOR (Slide chilled compartment thermistor)
- R.THERMISTOR (Refrigerator compartment thermistor)

MR-G50J-NZ

(ACTUAL WIRING DIAGRAM)







- I.THERMISTOR (Ice making compartment thermistor)
- V.THERMISTOR (Vegetable compartment thermistor)
- S.THERMISTOR (Versa compartment thermistor)
- DEF.THERMISTOR (Defrost thermistor)
- ICE-TRAY THERMISTOR (Ice making tray thermistor)
- F.THERMISTOR (Freezer compartment thermistor)
- C.THERMISTOR (Slide chilled compartment thermistor)
- R.THERMISTOR (Refrigerator compartment thermistor)


(When the doors are closed.)

MR-G50J-NZ

Unit : mm



REQUIRED SPACE FOR INSTALLATION




	R(L)	R(R)	I	S	V	F
H	782	782	214	214	361	361
W	284	456	284	456	745	745


- R(L) : Refrigerator compartment (Left)
- R(R) : Refrigerator compartment (Right)
- I : Ice making compartment
- S : Select compartment [Versa compartment]
- V : Vegetable compartment
- F : Freezer compartment

5 REFRIGERANT CIRCUIT

MR-G50J-NZ



6-1 FUNCTION OF OPERATION PANEL MR-G50J-NZ (1) Function of normal operation



Convenient function

Cooking timer

SELECT QUICK
Press switch and switch for 1 second at the same time. (⊙ is displayed.)
(Cooking timer can be released in the same way.)
Cooking timer mode is set and "0" blinks.

1
Set the time with switch. → Press to start → Alarm sound will announce the completion of cooking period.
(1-99 minutes) (To stop the timer halfway through the operation, press again).

Child lock

2
Press switch and switch for 3 seconds at the same time. (⌘ is displayed.)
(Child lock can be released in the same way.)

Ice making stop

3
Press to select "ice making compartment".
→ Select with switch.

ON/OFF of LED for bacteria removal from water tank

4
 to select "vegetable compartment".
Press switch and switch for 3 seconds at the same time. (✱ is displayed.)

When stopping quick mode halfway

Press switch again.

When stopping quick mode of all compartments at once

Press switch for about 3 seconds against one of the compartments which is in QUICK MODE.

※ To reset the unit to the initial setting, press for 3 seconds. The setting of the refrigerator compartment, vegetable compartment, and the freezer compartment will be set to "Middle", and fast cooling operation, energy-saving operation, and cooking timer setting for all compartments will be canceled.

To use "ice making compartment" as "refrigerator compartment"




- Press to select "ice making compartment".
- Press for about 3 seconds and let **REF** flash.
- After ice-making compartment is set to function as refrigerator, take ice or water out of the ice tray which are automatically dropped into ice storage bin. When ice-making function will not be used for a while, wash the water tank well with water and place it back after drying thoroughly.
- To get back to "ice making", just change the temperature setting.

Operating mode and Temperature range




Compartment	Mode	Temp range
Refrigerator compartment	Middle	Approx. 0 to 6°C
	Refrigerator	Approx. 0 to 6°C
Vera compartment	Chilled	Approx. -2 to 2°C
	Soft freezing (Middle)	Approx. -9 to -5°C
	Freezer	Approx. -18 to -16°C
Ice making compartment	Refrigerator	Approx. 0 to 6°C
	Ice making	Approx. -21 to -17°C
	Ice making stop	Approx. -21 to -17°C
Vegetable compartment	Middle	Approx. 3 to 9°C
Freezer compartment	Middle	Approx. -21 to -17°C

※The temp range above is based on the data measured at the center of each compartment with the door closed and with no food inside under the condition of ambient temperature 30°C. The range varies depending on circumstances.

(2) Demonstration mode for shop display

Demonstration mode is not available when the temperature of freezer compartment is -7°C or less even if  ,  and  are simultaneously pressed for about 5 seconds and a “beep” sound is heard. Cooling operation starts instead.

① Setting

- Within one minute after power supply is turned on, simultaneously press  ,  , and  switch for about 5 seconds with the door of ice making compartment left open. When the setting is complete, a “beep” sound is heard and “D” is displayed.




② Panel operation mode during demonstration mode

The panel operation mode changes to “manual” if any of the switches is pressed and it changes to “auto” if none of the switches is pressed within 3 minutes after demonstration mode is set.

Manual mode: Panel indication changes according to switch operation.

Auto mode: Panel indication is automatically changed.

③ Release

- Simultaneously press  ,  and  switch for about 5 seconds with the door of ice making compartment left open. When the function is released, a “beep” sound is heard. “D” disappears and the panel indication gets back to normal.




Note: Follow the procedure above to release demonstration mode as it cannot be released by simply turning on/off the power supply.

(3) Fine adjustment of temperature

Fine adjustment of temperature is available for refrigerator compartment, freezer compartment and versa compartment.


As for versa compartment, however, it is only available when the compartment is set to  or  .

① Setting

- Press  switch to select refrigerator compartment, freezer compartment or versa compartment.
- Simultaneously press  and  for about 3 seconds until a “beep” sound is heard.
- The indication changes as show in the right.



② Fine adjustments of temperature



Temperature adjustment is made by approximately $0.3\text{--}0.5^{\circ}\text{C}$ by pressing  and it is indicated with 15-steps bars on the panel. The temperature displayed on the panel, however, changes by 1°C and might not change according to fine adjustment.

Example of display:



In case of versa compartment

- Press  to make versa compartment function as refrigerator or freezer .

When the blinking marks on the display,  or  , are lit in 3 seconds, apply fine adjustment of temperature.


③ Release

Follow the same procedure as setting and the finely-adjusted temperatures are reset for refrigerator compartment, freezer compartment and versa compartment at once.

(4) Ice making test / Self-check

This function is not available during the following modes: Child lock, Demonstration, Cooking timer, Changing the rotational speed of compressor, and Error code display.

① Setting

- Press  for about five seconds.

② Operation and its display



- While automatic ice making is testing, the indication of ice making compartment setting blinks on LCD.
- When something is faulty, the error code is indicated.


③ Release

The test automatically finishes in 10 minutes and the error code changes to temperature display.

(5) Thermistor temperature check mode

① Setting

- With the door of ice making compartment left open, simultaneously press  and  for about 3 seconds until a “beep” sound is heard and “88” blinks.

- Press  with the door left open.


② Display

After the setting is complete, the kinds of thermistor and its temperature are alternately shown on the panel. In case of abnormality, the display returns to current temperature. Please note that the temperature detected by thermistor may be a little different from the real one due to the influence of refrigerator temperature.

Kind of thermistor	Defrosting	Refrigerator compartment	Slide chilled compartment	Ice making compartment	Versa compartment	Ice making tray	Vegetable compartment	Freezer compartment	Outside air
Display									
	(d)	(R)	(C)	(K)	(S)	(I)	(V)	(F)	(O)


③ Change of display

- While thermistor temperature check mode is set, press . A short beep sound is heard at each press and the thermistor is changed in the order below.



* The defrosting thermistor is always selected first at the beginning of the setting.

(Ex.) When defrost thermistor reads -28°C .



④ Release

- With the door of ice making compartment left open, simultaneously press and for about 3 seconds until a beep sound is heard. The temperature of thermistor disappears and the display gets back to current temperature.
- The function is automatically released one-hour later.
- Follow the procedure above to release this mode. For the prevention of the compressor, avoid releasing it by plugging and unplugging the power cord.

(6) Change mode of compressor rotational speed

Operation sound can be checked by changing the rotational speed of compressor. Always conduct a check while the compressor is operating and the “-” mark is not on the display, which shows the compressor stops. If the “-” mark is on the display, unplug the power cord and then plug it in a few seconds to operate the compressor. Also, this function is not available during the following modes: Child lock, Demonstration, Cooking timer, Thermistor temperature check and error code display.

① Setting

- With the door of ice making compartment left open, simultaneously press and for about 3 seconds until a “beep” sound is heard, and “88” blinks.


(Ex.) When the rotational speed is 52 rps

- Press with the door left open.



② Changing the rotational speed

- After the setting is complete, press and the rotational speed of compressor alternately changes in 6 steps. The rotational speed (rps) is shown on the panel. Basically the compressor starts operating at level 5, however, it depends on model or specification change.



* Note: Operation sound may get increased in the process of changing the speed, but that does not mean any problem. Check the operation sound when the rotation is stabilized.

③ ON and OFF of machine chamber fan motor

Under this function, fan motor in machine chamber can be switched on and off at each press of switch. The on/off state is shown with mark on the panel.

Machine chamber fan motor	Display of
ON	Displayed
OFF	Not displayed





④ Release

- With the door of ice making compartment left open, simultaneously press and for about 3 seconds until a “beep” sound is heard. The screen returns to the temperature display.
- The function is automatically released one-hour later.
- Follow the procedure above to release this function. For the prevention of the compressor, avoid releasing it by plugging and unplugging the power cord.

(7) Damper Operation Mode

During damper operation mode, the damper is forcibly opened and closed and the state of damper is shown on the panel.


① Setting

- With the ice making compartment door left open, simultaneously press ^{MODE}  and ^{QUICK}  for about 3 seconds until a “beep” sound is heard, and “88” blinks.
- With the door left open, simultaneously press ^{MODE}  and ^{SELECT}  for about 3 seconds until a “beep” sound is heard.

② Status display of each damper

Each compartment display turns on when each damper is open and turns off when each damper is closed.






Ex.) When all dampers are open;




③ How to make each damper open or close


Although the state is shown on the panel, check airflow and confirm the damper is really opened or closed. However, air does not come out when the door is closed, so put a magnet on the door switch to simulate the condition of the door closed.


● Change of display


Kind of damper	Refrigerator compartment	Slide chilled compartment	Ice making compartment	Versa compartment	Freezer compartment
Display	 (R)	 (C)	 (I)	 (S)	 (F)


(Ex.) When making the damper of refrigerator compartment open




(1) Press ^{SELECT}  to select the damper to be set up.

A “beep” sound is heard and the kind of damper is changed every time ^{SELECT}  is pressed.















(2) Press ^{QUICK}  to “8” to open the damper or “ε” to close the damper.



(3) Press ^{ECO}  for about 3 seconds to convey the setting to the damper.

A “beep” sound is heard if the setting has been conveyed. After the setting is conveyed, the damper starts operating and the display blinks. It stops blinking and starts to light when the operation stops automatically. Please note that the setting cannot be changed when the damper is operating.

As the damper of slide chilled compartment opens and closes in conjunction with the damper of refrigerator compartment, it is necessary to set them to the either of the following.

		How to set
Open	Open	Set  to  and then set  to  .
Close	Open	Not available
Open	Close	Set  to  and then set  to  .
Close	Close	Set  to  .

④ Release





- With the door of ice making compartment left open, simultaneously press ^{MODE}  and ^{QUICK}  for about 3 seconds until a “beep” sound is heard. The screen returns to the temperature display.
- This function is not automatically released.
- Follow the procedure above to release this function. For the prevention of the compressor, avoid releasing it by plugging and unplugging the power cord.

(8) Error history display mode

Error history can be observed in the error history display mode.

Use this mode when the actual problem of the refrigerator is different from the error which was displayed at the service-call received.

① Setting

- Open the door of the ice making compartment, and press  and  together for 3 seconds until a “beep” is heard and “**EE**” blinks.
- With the door left open, press  and  together for 3 seconds until a “beep” is heard.

② Display details

- Same as the error display and trouble locating. (Refer to 6.2(3))
- When there is no recorded error, “—” will be displayed.
- When several errors have occurred, error will be displayed in the increasing numerical order, as in the error display and trouble locating.
(Ex.) In case errors in the ice tray thermistor (E10), refrigerator thermistor (E13) and refrigerator fan motor (E31) have occurred:

E → 10 → 13 → 31 → E → 10 → 13 → 31 ……

TEMP

E


↓ ↑

TEMP



33

(Ex.) When there is problem with the ice maker gear box.

③ Check points and resetting the error history

- Follow the treatment procedures shown in the self-check.
- After the treatment, press  for 3 seconds to reset the error history.
“—” will be displayed when the data is reset successfully.
- Perform the self-check again (Refer to 6.2) to confirm there are no dysfunctions.

④ Release

- Open the door of the ice making compartment, and press  and  together for 3 seconds until a “beep” is heard.
The display will return to the normal temperature display.
- Function is automatically released in an hour.
- Follow the procedure above to release this function. For the prevention of the compressor, avoid releasing it by plugging and unplugging the power cord.

Door Buzzer System :

Door buzzer has been installed so that one will not forget to close the door.

When the door of refrigerator compartment or ice making compartment is left open for a minute, the buzzer starts ringing and informs that the door needs to be closed.

When door is left open for:	1 minute- 4 minutes	More than 5 minutes
Buzzer	Buzzer rings every 1 minute	Keeps ringing

The buzzer will stop ringing as soon as the door is closed.

However, this buzzer system does not work when the door is not widely open like when something is pinched between the door and refrigerator.

If the door is not closed completely, the temperature inside the refrigerator will rise and it will be a cause of spoiling the food inside.

When the buzzer does not stop even if all the doors are closed, abnormality may occur in door switch.

If the buzzer keeps ringing and annoying, it can be stopped by the following operations.

① Perform the ice making test operation.

(Note: If the test is conducted with water in the ice tray, water may fall into the ice storage bin because the tray is rolled over in the ice making operation.)

Buzzer sounds when a trouble is found in refrigerator fan motor or in machine chamber fan motor. The buzzer sounds every time the door is closed until the fan motor gets to operate correctly.


(Check the error code by following the steps in Specification of display in self-check result on page 14.)

6-2 FLOWCHART OF SELF-CHECK

MR-G50J-NZ

(1) Troubleshooting with self-check

This refrigerator has self-check feature to clarify and indicate where & what the trouble is. You can perform operation checks and identify malfunction of electric or electronic parts. Error history is recorded and can be displayed by the refrigerator.




●Self-check and error display method and operation

	Item	Operation method	Display or self-check operation	Display time	Others
Self-check (current displayed error)	①Ice making test operation. All items except (*6) listed up on the table at page 17 will be checked.	Press the MODE switch for 5 seconds.	1. Conduct the automatic ice making test. (The display of ice making compartment setting is blinked) 2. When trouble is found, all error codes except E50-E55 are displayed. 3. When error is not found, nothing is displayed.	For 10 minutes after setting.	Self-check is not available during child lock, cooking timer, changing the rotational speed of compressor, checking the temperature of thermistor, damper operation and demonstration modes.
	②Power input. All items except (*6) listed up on the table at page 17 will be checked.	Plug the power cord into outlet.	1. When trouble is found, all trouble except E50-E55 are displayed. 2. When error is not found, nothing is displayed.	For 10 minutes after power is supplied.	Self-check is not available during demonstration mode.
Display error history.	③Error history	Refer to 6.2(3) Error history display mode.	1. When trouble is found, all trouble except E50-E55 are displayed. 2. When error is not found, nothing is displayed.	For one hour after setting, or until mode is released.	Self-check is not available during child lock, cooking timer, changing the rotational speed of compressor, checking the temperature of thermistor, damper operation and demonstration modes.

●Release of self-check display mode

self-check finishes automatically. Error cord display is automatically released 10 minutes later.

(2) Timing in self-check

- Trouble of Defrost heater : Self-check is conducted after defrosting.
(Make sure to confirm the display before unplugging the power cord because it is automatically reset once the power cord is pulled out.)
- Trouble of Ice maker : Press the  switch on the panel for 5 seconds. (Ice making test mode.)
The setting of ice making compartment blinks on LCD during the test operation.
- Trouble of Fan motor : Open the door and then closed it.
When abnormality is found in fan motor, buzzer sound is heard every time the door is closed.
- Trouble of Inverter : Check the error when compressor starts up or is operating.
- Trouble of Thermistor : Self-check is continuously working

(3) Error display and trouble locating

1. Display details

After conducting the self-check by referring to 6-2(1), error codes are displayed in the temperature display section. "E" and two digit error code flashes alternately as shown in the right figure. When several errors occur, they are displayed alternately. However, the error whose code has a smaller number has priority to be displayed first.

(Ex.) In case the errors of ice tray thermistor (E10), refrigerator thermistor (E13) and refrigerator fan motor (E31) are happening simultaneously;

E → 10 → 13 → 31 → E → 10 → 13 → 31

* For 2 minutes in self-check, a high-tone sound is heard due to the operation check of damper.

TEMP

E



TEMP

33

2. Check point and treatment

(Ex.) When ice maker gear box is defective.

Display	Error code	Trouble	Detecting method (*3)	Check point	Treatment	Control	
Self-check	Testing	(*1)	Ice maker is under testing				
	LCD	E 01	(*5) Communication error of operation panel	When the following communication errors occur between control board and operation P.C. board: •They transmit and receive data that has nothing to do with settings. •They cannot transmit and receive data each other for about two seconds.	1. Connector CN8K, CN7S on control board 4-pin relay connector (hinge) 4-pin connector on operation P.C. board ----- 2. Trouble of control board and operation P.C. board	Repair the contact failure. ----- Replace	Keep the same operation as the one before the communication error has occurred.
		E 02	Communication error of inverter	When abnormality is found in the communication between refrigerator control circuit and inverter control circuit in control board. (When they do not transmit and receive data for 10 seconds.)		Replace the control board.	Compressor OFF.
		E 03	Trouble of model judgement	When the model of control board is different from the one of operation P.C. board.	1. Check the model name of control board ----- 2. Check the operation p.c. board.	Replace ----- Replace	Keep operating the unit, and conduct error code indication only.
		E 10	Trouble of ice making tray thermistor	When there is a short or open circuit in the ice making tray thermistor.	1. Connector CN7S on control board, Ice gear box 6-pin relay connector, 8-pin relay connector ----- 2. Check the resistance of thermistor.	Repair the contact failure. ----- Replace	When the compartment door has been closed for 3 hours and when freezer compartment thermistor is -10°C or less, ice-detecting operation starts.
		E 11	Trouble of freezer compartment thermistor	When there is a short or open circuit in the freezer compartment thermistor.	1. Connector CN7S on control board. 6-pin relay connector ----- 2. Check the resistance of thermistor.	Repair the contact failure. ----- Replace	After 10 minutes off, the compressor repeats 30-minute ON and 20-minute OFF.
		E 12	Trouble of defrost thermistor	When there is a short or open circuit in the defrost thermistor.	1. Connector CN7S on control board. 2-pin relay connector ----- 2. Check the resistance of thermistor.	Repair the contact failure. ----- Replace	The defrost heater won't be turned ON.
		E 13	Trouble of refrigerator thermistor	When there is a short or open circuit in the refrigerator compartment thermistor.	1. Connector CN7S on control board, 4-pin relay connector ----- 2. Check the resistance of thermistor.	Repair the contact failure. ----- Replace	Synchronize the open/close status of R damper with that of C damper.
		E 14	Trouble of chilled compartment thermistor	When there is a short or open circuit in the chilled compartment thermistor.	1. Connector CN7S, on control board, 6-pin relay connector ----- 2. Check the resistance of thermistor.	Repair the contact failure. ----- Replace	Synchronize the open/close status of C damper with that of R damper.
		E 15	Trouble of versa compartment thermistor	When there is a short or open circuit in the versa compartment thermistor.	1. Connector CN7S on control board, 6-pin relay connector ----- 2. Check the resistance of thermistor.	Repair the contact failure. ----- Replace	•When S-compartment is used as "freezer": S-damper is open when compressor is turned on, S-damper is closed when compressor is turned off. •When S-compartment is used other than "freezer": S-damper remains open for the first 3 minutes and then closed for the rest of time. S-compartment: Versa(select) compartment.
E 16		Trouble of vegetable compartment thermistor	When there is a short or open circuit in the vegetable compartment thermistor.	1. Connector CN7S on control board, 4-pin relay connector ----- 2. Check the resistance of thermistor.	Repair the contact failure. ----- Replace	•When R-damper is open, V-heater is turned on. •When R-damper is closed, V-heater is turned off.	




Display	Error code	Trouble	Detecting method (*3)	Check point	Treatment	Control
Self-check LCD	E 17	Trouble of ice making compartment thermistor	When there is a short or open circuit in the ice making compartment thermistor.	1. Connector CN7S on control board, 6-pin, 9-pin relay connector	Repair the contact failure.	<ul style="list-style-type: none"> When ice making compartment is used as "refrigerator", synchronize I-damper with R-damper. When ice making compartment is used as "ice making", synchronize I-damper with F-damper.
				2. Check the resistance of thermistor.	Replace	
	E 18	Trouble of outside air thermistor	When there is a short or open circuit in the outside air thermistor.		Replace the operation P.C. board.	Compressor is activated at "Speed-level 2."
	E 30	Trouble of defrost heater (*6)	When defrosting is not finished in 2 hours.	1. Connector CN2A on control board Defrost heater plug and receptacle, 1-pin relay connector Thermal fuse 4-pin, 8-pin relay connector	Repair the contact failure.	The defrost heater is stopped and if the next defrosting finishes in 2 hours, the error code will disappear .
				2. Check the resistance of defrost heater.	Replace	
				3. Check the continuity of thermal fuse.	Replace	
	E 31	Trouble of refrigerator fan motor	<ul style="list-style-type: none"> When motor doesn't rotate even though power is on. When the waveform, which indicates the rotation times of motor, cannot be detected. 	1. Connector CN4D on control board, Refrigerator fan motor 6-pin relay connector	Repair the contact failure.	<ul style="list-style-type: none"> 3 minutes later, the refrigerator fan motor is reactivated to be checked. Until the fan motor gets to operate correctly, the buzzer sounds every time the door is closed.
				2. Check refrigerator fan motor operation.	Replace	
	E 32	Trouble of machine chamber fan motor	<ul style="list-style-type: none"> When motor doesn't rotate even though power is on. When the waveform, which indicates the rotation times of motor, cannot be detected. 	1. Connector CN4D on control board, 4-pin connector, 4-pin relay connector	Repair the contact failure.	<ul style="list-style-type: none"> 3 minutes later, the machine chamber fan motor is reactivated to be checked. Until the fan motor gets to operate correctly, the buzzer sounds every time the door is closed.
				2. Check machine chamber fan motor operation.	Replace	
	E 33	Trouble of ice maker gear box	When the gear box operation is not finished in 30 seconds.	1. Connector CN8K on control board, Ice gear box 6-pin relay connector, 8-pin relay connector	Repair the contact failure.	100 minutes later, the gear box is reactivated to be checked again.
				2. Ice gear box frozen point	Replace	
				3. Check the trouble of the ice gear box with the ice making test operation.	Replace	
	E 34	Clogging of refrigerant pipe or trouble related to compressor	(T0: Defrost thermistor temperature at power input, T1: Defrost thermistor temperature when 15 minutes have passed from the power input) <ul style="list-style-type: none"> When the difference between T0 and T1 is $T0 \leq T1$. (*5) 	Check the compressor and the pipe.		When cooling operation returns to normal condition, the display of error code disappears.
E 41	Trouble of electromagnetic three-way valve	When defrost thermistor reads -10°C or above in five minutes after the compressor's startup. (*5)	Connector CN9D on control board 5-pin connector in machine chamber	Repair the contact failure.	Check the operation of electromagnetic three-way valve and then open the valve.	
E 50	Trouble of inverter circuit (*6)	<ul style="list-style-type: none"> When there is any trouble in the circuit which detects current of compressor. When the range of bus-bar voltage is not approx. DC 260-390V. When the inverter driving software malfunctions. 	Refer to "Compressor does not operate" at page 21.		The compressor is suspended and reactivated 10 minutes later.	
E 51	Trouble of bus-bar voltage (*6)					
E 52	Trouble of inverter software reset function					
E 53	Trouble of startup, synchronization or overcurrent detection (*6)					
E 54	Trouble of power supply voltage (*6)	When bus-bar voltage (full wave voltage) is DC 390V or above in power input.	1. Different voltage of power supply outlet 2. Trouble of relay in the circuit on the control board	Replace the control board.	Refrigerator compartment room light OFF Heaters. OFF	
E 55	Trouble of control board (*6) (EEPROM related trouble)	EEPROM (IC11M) accumulates data necessary for control. <ul style="list-style-type: none"> When the data are not input accurately. When microcomputer cannot read the data. 		Replace the control board.	When abnormality occurs in power input, the compressor is suspended for 10 minutes. When abnormality occurs in normal operation, the compressor keeps operating.	
E 56	Defective wiring continuity or trouble of control board	The errors 50 to 53 keep occurring over one and a half hour. (the situation, which compressor cannot be operated, continues.) Overcurrent detection error occurred before the compressor is activated.	Refer to "Compressor does not operate" at page.22.		<ul style="list-style-type: none"> Error display starts after it is regarded as E56. Error display continues until defrosting starts or cooling operation gets back to normal. (Error display doesn't disappear by unplugging and plugging the power cord. 7) Try to restart compressor every 3 minutes. 	

*1 : The setting of ice making compartment will be displayed and blinks during or after ice making test operation.
 *2 : This operation is called the recovery operation:
 If the damper has not operated ever once during the compressor operation, make the damper operate when the compressor stops.
 *3 : When the resistance is $\infty\Omega$, the circuit is deemed open-circuited.
 When the resistance is 0Ω , the circuit is deemed short-circuited.
 *4 : Once E01 is detected, other errors would be ignored and not displayed on the panel.
 *5 : Characteristic value may change in order to improve the product.
 *6 : The error codes E50 to E55 are not displayed even if those abnormalities occur at power input.
 Therefore, be sure to perform ice making test operation in order to check if any abnormality indicated by these error codes occurs. (See page 14.)
 *7 : If those errors still continue for 1minute after the restart, E56 will be displayed again.

6-3 BLOCK DIAGRAM OF PRINTED CIRCUIT BOARD

MR-G50J-NZ



6-4 AUTO ICE MAKER

MR-G50J-NZ

(1) Ice making cycle

Water supply

The ice tray is filled with water from the water tank.

Ice making

Ice tray thermistor watches and controls the ice making operation.


Ice ejection

After the detection lever checks the amount of ice, the ice tray is rolled over for ice ejection.


Ice stock

Ice is stocked in the ice server. Ice making capacity is about 100 - 120 cubes a day. Stock capacity of Ice cubes is about 100 cubes.

(2) Automatic ice maker circuit



(3) Operation by ice making test





*Never touch the automatic ice maker while it is operating.

After the operational test, a popping sound is heard several times because the operation of three-way valve is checked automatically. During the operation, do not insert a hand into the automatic ice maker.

(4) Maintenance for water pump and water pipe

Water pump & Light-type bacteria removing filter

1. Pull out the pipe.
2. Turn the tank pump to detach.
3. Pull out the tank pipe, turn the cap to remove, and then wash the propeller with water.



4. Remove the light-type bacteria removing filter and wash it in water.



Normally the filter need not be replaced. However, replace it in the following condition:

- When the filter is clogged by passing something other than water through the filter.
 - When the filter is broken.
- In such a case, contact the dealer that you purchased this refrigerator.

5. Put the parts back in the reverse order of disassembly.


Water pipe - Tank holder

1. Pull out water supply pipe. Wipe the tank holder with clean cloth.



2. Separate pieces and wash with water.
3. Reverse steps to replace the pipe.

- Twist the aluminum pipe to replace it.






(5) Troubleshooting for automatic ice-maker

Trouble with ice-making	Water or ice is on the ice tray	The ice does not come out from the tray	The ice-maker gear box may be defective, cooling may be poor or ice cubes may be full in the server.		
			1. Check inside of the ice server.	<ul style="list-style-type: none"> •Ice cubes are not stored flatly and the amount is detected as full. •Food inside the ice server <p>→ Inspection</p>	
			2. Measure the resistance of ice tray thermistor circuit.	<ul style="list-style-type: none"> •Open circuit ($\infty\Omega$) or short circuit (0Ω) <p>→ Replace the ice tray thermistor.</p>	
	No water or ice in the ice tray	Water in water saucer	No waterdrops in water saucer	3. Check if the temperature of the freezer compartment is cool enough. (It takes longer to make ice during summer time or if the door is frequently opened.)	<ul style="list-style-type: none"> •Not enough <p>→ Poor cooling</p>
				The water saucer may be defective, or the ice tray may get cracked.	
				4. Check the water pipe between the refrigerator compartment and freezer compartment for dirt, and foreign objects.	<ul style="list-style-type: none"> •Clogging •Freezing (For freezing, check the pipe heater resistance.) <p>→ Clean the water pipe. → Defrost</p>
				5. Check the condition of ice tray.	<ul style="list-style-type: none"> •Broken or cracked •Not placed properly <p>→ Replace the tray. → Reinstall it properly.</p>
				6. Disassemble the water pump and check the inside of the pipe.	<ul style="list-style-type: none"> •Dirt or foreign objects <p>→ Repair and explain to the user for proper usage.</p>
				7. Tank pipe is clogged, has a hole or is not properly installed.	<ul style="list-style-type: none"> •Clogging, disconnecting •Hole or crack <p>→ Clean / Reinstall it properly. → Change the tank pipe.</p>
Water in the tank holder	No waterdrops in water saucer	No waterdrops in water saucer	8. Check the motor coil resistance.	<ul style="list-style-type: none"> •Open or short circuit <p>→ Check the water pump.</p>	
			9. Check if there are any dirt or foreign object which are difficult to remove in the water tank. Also, check if there is any crack or deformation on the tank.	<ul style="list-style-type: none"> •Crack or deformation <p>→ Change the water tank.</p>	
Chained ice, Water leaking from the ice server	No waterdrops in water saucer	No waterdrops in water saucer	10. Check the water pipe for dirt, and foreign objects. Also, check the water pipe position and connection.	<ul style="list-style-type: none"> •Clogging, disconnecting •Hole or crack <p>→ Clean / Reinstall it properly. → Replace the pipe.</p>	
			11. Check the water pipe (between F. compartment and R. compartment) for clogging.	<ul style="list-style-type: none"> •Clogging <p>→ Clean / Remove the dirt.</p>	
Chained ice, Water leaking from the ice server	No waterdrops in water saucer	No waterdrops in water saucer	12. Check the water pump operation by the ice-making test.	<ul style="list-style-type: none"> •Water filling time is longer than 9 seconds. <p>→ Replace the control board.</p>	
			13. Water spill at the installation of water tank or more water over the full water level may cause to from chained ice.		
Chained ice, Water leaking from the ice server	No waterdrops in water saucer	No waterdrops in water saucer	14. Measure the water pump coil resistance.	<ul style="list-style-type: none"> •Open or short circuit <p>→ Change the water pump motor.</p>	

6-5 FLOWCHART OF TROUBLE CRITERION

MR-G50J-NZ







Inverter-related indication “Compressor does not operate”

Error code	Abnormality	Possible cause	Symptom	Treatment
E50	Trouble of inverter circuit	<ul style="list-style-type: none"> When there is any trouble in the circuit which detects phase current of compressor. 	Compressor does not rotate.	Replace the control board.
E51	Bus-bar voltage is abnormal.	<ul style="list-style-type: none"> Power supply voltage is abnormal. Defective reactor on the N/F board 	Compressor does not rotate.	<pre> graph TD Start([Start]) --> Measure{Measure the voltage of power supply.} Measure -- "160V or more" --> Arrange1[Arrange power supply to obtain the rated voltage, 180-280V.] Measure -- "280V or more" --> Arrange2[Arrange power supply to make the voltage within 180-280V and conduct the following checks.] Arrange2 --> AC230V{Does AC230V run between CN51 terminals ① and ③, on the control board? (See page 32.)} AC230V -- Yes --> ReplaceCB[Replace the control board.] AC230V -- No --> CheckConn[Check the connection between filter board and control board.] CheckConn -- Normal --> ReplaceFB[Replace the filter board.] CheckConn -- Abnormal --> Connect[Connect them properly.] </pre>
E52	Trouble of inverter software reset function	<ul style="list-style-type: none"> When the inverter driving software malfunctions. 	Compressor does not rotate.	<pre> graph TD Start([Start]) --> Unplug[Unplug the power cord and then plug it in 10 minutes.] Unplug --> CheckError[Check the error code by performing the ice making test operation.] CheckError -- "E52 display again." --> ReplaceCB[Replace the control board.] CheckError -- "No error code display" --> Explain[Explanation to customer.] </pre>
E53	<ul style="list-style-type: none"> Abnormal start-up Abnormal synchronization Trouble of overcurrent detection 	<ul style="list-style-type: none"> Compressor motor gets locked. Defective circuit on control board Defective contact of CN50G on control board Defective contact of machine chamber 6-pin connector 	Compressor does not rotate.	<pre> graph TD Start([Start]) --> Disconnect[Disconnect 6-pin connector in machine chamber to check resistance between each terminal of ①, ② and ③: Are they approx. 9.3Ω (20°C)?] Disconnect -- No --> Measure[Measure the resistance of compressor's winding between each terminal of ①, ② and ③: Are they approx. 9.3Ω (20°C)?] Measure -- No --> ExchangeUnit[Exchange the unit.] Measure -- Yes --> ReplaceLead[*Replace lead wire assembly C.] ReplaceLead --> Energized{*Is compressor energized at startup?} Energized -- Yes --> ExchangeUnit Energized -- No --> CheckConn[Check the connection of the connector CN50G on the control board or the machine chamber 6-pin connector.] CheckConn -- Normal --> ReplaceCB[Replace the control board.] CheckConn -- Abnormal --> Connect[Connect them properly.] </pre> <p>*If control board is normal, compressor is energized every 10 minutes. Compressor vibrates at startup when it is being energized. Touch it with your hand to check.</p>


Inverter-related indication “Compressor does not operate”

Error code	Abnormality	Possible cause	Symptom	Treatment
E55	<ul style="list-style-type: none"> •Defective wiring continuity •Trouble of the control board 	<ul style="list-style-type: none"> •Defective connection of connectors related to compressor (board-side, relay, comp-side) •Defective wiring continuity of the compressor •Trouble of control board •Trouble of compressor 	<p>(1) or (2)</p> <p>(1) Compressor can not be activated for more than 1.5 hours</p> <p>(2) Overcurrent detection error occurred before the compressor is activated.</p>	<p>1. Locate the trouble and decide the treatment</p> <ul style="list-style-type: none"> •Decide the treatment by checking the followings. <ul style="list-style-type: none"> (1) Defective connector connections. (board-side, relay, comp-side) (2) Resistance of compressor's winding <p>2. Flowchart of troubleshooting</p> <div style="text-align: right; margin-bottom: 10px;"> Check Treatment </div>  <pre> graph TD Start([start]) --> Q1{Connector CN50G on the control board is properly connected?} Q1 -- No --> T1[Connect properly.] Q1 -- Yes --> Q2{6-pin relay connector in machine chamber is properly connected?} Q2 -- No --> T1 Q2 -- Yes --> Q3{The connector of compressor is properly connected?} Q3 -- No --> T1 Q3 -- Yes --> Q4{Disconnect 6-pin relay connector in machine chamber and measure the resistance between each terminal of ①, ② and ③ (Point 1). Approx. 9.3Ω (At 20°C)?} Q4 -- No --> Q5{Measure the resistance of compressor's winding between each terminal (Point 2). Approx. 9.3Ω (At 20°C)?} Q5 -- No --> T2[Exchange the unit] Q5 -- Yes --> T3[Replace the lead wire connected to compressor.] Q4 -- Yes --> Q6{Is compressor being energized at startup?} Q6 -- No --> T4[Replace the control board.] Q6 -- Yes --> T5[Exchange the unit] Note[Replace it only when error display keeps blinking even though all the above mentioned connectors are properly connected.] -.-> T5 </pre> <p>3. Recheck after treatment</p> <ul style="list-style-type: none"> •After any treatment is tried, unplug and plug power cord again to check if the compressor operates properly. •If the compressor can operate properly for more than 1 minute after power cord is plugged again, it's presumed that the cause of trouble is eliminated. <p>*If the cause of trouble cannot be eliminated, "E55" will be displayed again 1 minute later after the power cord is plugged again.</p> <p>*If the control board has been replaced, E55 won't be displayed even though the cause of trouble is still not eliminated. In such a case, perform the ice making test operation to check what the error is. At the same time, also confirm that the compressor is operating for more than 3 minutes and each compartment is getting cooled.</p>




Poor cooling

[4] Poor defrosting





[5] The refrigerator fan motor does not work





Door switch for refrigerator compartment (right and left) and ice making compartment.

Doors	Any one of the doors are open	R-door (right, left): closed Door of the ice making compartment : closed
	 etc	 ① ②
2-Pin connector Between ① and ②	OFF	ON

*If any one of those doors are open, the switch between ① and ②, terminals of 2-pin connector, will be OFF




















6-6 TROUBLE CRITERION OF MAIN PARTS





MR-G50J-NZ




Components/ Part Name	Check Method and Criterion		Parts Mounted Position																											
Compressor	 <p>Measure the resistance with a tester.</p>	<table border="1"> <tr> <td colspan="2">Model</td> <td>ETI100E13DAH</td> </tr> <tr> <td>Rated input</td> <td>W</td> <td>45/159 (1620/4800rpm)</td> </tr> <tr> <td>Starting current</td> <td>A</td> <td>2.0</td> </tr> <tr> <td>Running current</td> <td>A</td> <td>0.03/2.19 (1620/4800rpm)</td> </tr> <tr> <td colspan="2"></td> <td>Normal</td> </tr> <tr> <td colspan="2"></td> <td>Abnormal (faulty)</td> </tr> <tr> <td colspan="2">Winding (Black-White) (White-Red) (Red-Black)</td> <td>9.3 Ω (20°C) Open (∞Ω) or short circuit (0Ω)</td> </tr> </table>	Model		ETI100E13DAH	Rated input	W	45/159 (1620/4800rpm)	Starting current	A	2.0	Running current	A	0.03/2.19 (1620/4800rpm)			Normal			Abnormal (faulty)	Winding (Black-White) (White-Red) (Red-Black)		9.3 Ω (20°C) Open (∞Ω) or short circuit (0Ω)	In the machine chamber at the rear side of the frame.						
Model		ETI100E13DAH																												
Rated input	W	45/159 (1620/4800rpm)																												
Starting current	A	2.0																												
Running current	A	0.03/2.19 (1620/4800rpm)																												
		Normal																												
		Abnormal (faulty)																												
Winding (Black-White) (White-Red) (Red-Black)		9.3 Ω (20°C) Open (∞Ω) or short circuit (0Ω)																												
Motor protector	 <p>Measure the resistance with a tester. (Ambient temperature : Room temperature)</p>	<table border="1"> <tr> <td colspan="2">Model</td> <td>MM3-71CCV</td> </tr> <tr> <td rowspan="2">Connected point</td> <td>Open</td> <td>100 ±50 °C or more Energize it at 17.0A, 25°C for 16 seconds at the longest.</td> </tr> <tr> <td>Close</td> <td>61±8°C or less</td> </tr> <tr> <td colspan="2"></td> <td>Normal</td> </tr> <tr> <td colspan="2"></td> <td>Abnormal (faulty)</td> </tr> <tr> <td colspan="2"></td> <td>Less than 1Ω</td> </tr> <tr> <td colspan="2"></td> <td>Open circuit (∞Ω)</td> </tr> </table>	Model		MM3-71CCV	Connected point	Open	100 ±50 °C or more Energize it at 17.0A, 25°C for 16 seconds at the longest.	Close	61±8°C or less			Normal			Abnormal (faulty)			Less than 1Ω			Open circuit (∞Ω)	In the machine chamber at the rear side of the frame.							
Model		MM3-71CCV																												
Connected point	Open	100 ±50 °C or more Energize it at 17.0A, 25°C for 16 seconds at the longest.																												
	Close	61±8°C or less																												
		Normal																												
		Abnormal (faulty)																												
		Less than 1Ω																												
		Open circuit (∞Ω)																												
Refrigerator fan motor	 <p>①②③④ : Pin No.</p>	<table border="1"> <tr> <td colspan="2">Model</td> <td>UDQM002B3</td> </tr> <tr> <td colspan="2"></td> <td>DC brushless</td> </tr> <tr> <td colspan="2">Number of pole</td> <td>10</td> </tr> <tr> <td colspan="2">Diameter</td> <td>φ150 (Mixed flow fan)</td> </tr> <tr> <td colspan="2"></td> <td>Normal</td> </tr> <tr> <td colspan="2"></td> <td>Abnormal (faulty)</td> </tr> <tr> <td colspan="2">Between ① and ④ (GND and IC Power): About 12 kΩ</td> <td>Between ① and ④ : open circuit (∞Ω)</td> </tr> <tr> <td colspan="2">Between ③ and ④ (Power and IC Power): ∞Ω</td> <td>Between ③ and ④ : short circuit (0Ω)</td> </tr> </table> 	Model		UDQM002B3			DC brushless	Number of pole		10	Diameter		φ150 (Mixed flow fan)			Normal			Abnormal (faulty)	Between ① and ④ (GND and IC Power): About 12 kΩ		Between ① and ④ : open circuit (∞Ω)	Between ③ and ④ (Power and IC Power): ∞Ω		Between ③ and ④ : short circuit (0Ω)	In the fan grille of the freezer compartment.			
Model		UDQM002B3																												
		DC brushless																												
Number of pole		10																												
Diameter		φ150 (Mixed flow fan)																												
		Normal																												
		Abnormal (faulty)																												
Between ① and ④ (GND and IC Power): About 12 kΩ		Between ① and ④ : open circuit (∞Ω)																												
Between ③ and ④ (Power and IC Power): ∞Ω		Between ③ and ④ : short circuit (0Ω)																												
Machine chamber fan motor	 <p>①②③④ : Pin No.</p>	<table border="1"> <tr> <td colspan="2">Model</td> <td>UDQM004B3</td> </tr> <tr> <td colspan="2"></td> <td>DC brushless</td> </tr> <tr> <td colspan="2">Number of pole</td> <td>10</td> </tr> <tr> <td colspan="2">Diameter</td> <td>φ140 (Extra fan)</td> </tr> <tr> <td colspan="2">Operation method</td> <td>During compressor operation</td> </tr> <tr> <td colspan="2"></td> <td>Normal</td> </tr> <tr> <td colspan="2"></td> <td>Abnormal (faulty)</td> </tr> <tr> <td colspan="2">Between ① and ④ (GND and IC Power): About 9 kΩ</td> <td>Between ① and ④ : open circuit (∞Ω)</td> </tr> <tr> <td colspan="2">Between ③ and ④ (Power and IC Power): ∞Ω</td> <td>Between ③ and ④ : short circuit (0Ω)</td> </tr> </table> 	Model		UDQM004B3			DC brushless	Number of pole		10	Diameter		φ140 (Extra fan)	Operation method		During compressor operation			Normal			Abnormal (faulty)	Between ① and ④ (GND and IC Power): About 9 kΩ		Between ① and ④ : open circuit (∞Ω)	Between ③ and ④ (Power and IC Power): ∞Ω		Between ③ and ④ : short circuit (0Ω)	In the machine chamber at the rear side of the frame.
Model		UDQM004B3																												
		DC brushless																												
Number of pole		10																												
Diameter		φ140 (Extra fan)																												
Operation method		During compressor operation																												
		Normal																												
		Abnormal (faulty)																												
Between ① and ④ (GND and IC Power): About 9 kΩ		Between ① and ④ : open circuit (∞Ω)																												
Between ③ and ④ (Power and IC Power): ∞Ω		Between ③ and ④ : short circuit (0Ω)																												



Components/ Part Name	Check Method and Criterion	Parts Mounted Position						
Water pump motor	Measure the resistance with a tester. (Ambient temperature : Room temperature)  <table border="1" data-bbox="794 394 1278 517"> <thead> <tr> <th>Normal</th> <th>Abnormal (faulty)</th> </tr> </thead> <tbody> <tr> <td>16Ω (Approx.)</td> <td>Open (∞Ω) or short circuit (0Ω)</td> </tr> </tbody> </table>	Normal	Abnormal (faulty)	16Ω (Approx.)	Open (∞Ω) or short circuit (0Ω)	Under the water tank holder in refrigerator compartment.		
Normal	Abnormal (faulty)							
16Ω (Approx.)	Open (∞Ω) or short circuit (0Ω)							
Motor damper for refrigerator compartment/ slide chilled compartment	Measure the winding resistance. <table border="1" data-bbox="544 629 1278 792"> <thead> <tr> <th>Winding (Blue-White / Red-Yellow)</th> <th>Normal</th> <th>Abnormal (faulty)</th> </tr> </thead> <tbody> <tr> <td></td> <td>415Ω (Approx.)</td> <td>Open (∞Ω) or short circuit (0Ω)</td> </tr> </tbody> </table>  	Winding (Blue-White / Red-Yellow)	Normal	Abnormal (faulty)		415Ω (Approx.)	Open (∞Ω) or short circuit (0Ω)	In the control panel for refrigerator compartment. Connector is at the left-back bottom of refrigerator compartment.
Winding (Blue-White / Red-Yellow)	Normal	Abnormal (faulty)						
	415Ω (Approx.)	Open (∞Ω) or short circuit (0Ω)						
Motor damper for ice making compartment/ versa compartment	Measure the winding resistance. <table border="1" data-bbox="544 1151 1278 1314"> <thead> <tr> <th>Winding (Blue-White / Red-Yellow)</th> <th>Normal</th> <th>Abnormal (faulty)</th> </tr> </thead> <tbody> <tr> <td></td> <td>415Ω (Approx.)</td> <td>Open (∞Ω) or short circuit (0Ω)</td> </tr> </tbody> </table>  	Winding (Blue-White / Red-Yellow)	Normal	Abnormal (faulty)		415Ω (Approx.)	Open (∞Ω) or short circuit (0Ω)	In the fan grille for freezer compartment. Connector is at the back of versa compartment.
Winding (Blue-White / Red-Yellow)	Normal	Abnormal (faulty)						
	415Ω (Approx.)	Open (∞Ω) or short circuit (0Ω)						
Motor damper for freezer compartment	Measure the winding resistance. <table border="1" data-bbox="544 1688 1278 1852"> <thead> <tr> <th>Winding (Blue-White / Red-Yellow)</th> <th>Normal</th> <th>Abnormal (faulty)</th> </tr> </thead> <tbody> <tr> <td></td> <td>415Ω (Approx.)</td> <td>Open (∞Ω) or short circuit (0Ω)</td> </tr> </tbody> </table>  	Winding (Blue-White / Red-Yellow)	Normal	Abnormal (faulty)		415Ω (Approx.)	Open (∞Ω) or short circuit (0Ω)	In the fan grille for freezer compartment. Connector is at the left-back bottom of vegetable compartment.
Winding (Blue-White / Red-Yellow)	Normal	Abnormal (faulty)						
	415Ω (Approx.)	Open (∞Ω) or short circuit (0Ω)						









Components/ Part Name	Check Method and Criterion	Parts Mounted Position										
Defrost heater	<table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">Rated input</td> <td style="width: 10%;">W</td> <td style="width: 75%; text-align: center;">163</td> </tr> <tr> <td colspan="2">Operation method</td> <td>The heater is energized while defrosting. (Defrosting is finished when the evaporator is $14 \pm 1.5^{\circ}\text{C}$ or more)</td> </tr> </table> <p>Measure the resistance with a tester. (Ambient temperature : Room temperature)</p>  <table border="1" style="width: 100%; margin-top: 10px;"> <tr> <td style="width: 50%; text-align: center;">Normal</td> <td style="width: 50%; text-align: center;">Abnormal (faulty)</td> </tr> <tr> <td style="text-align: center;">325Ω (Approx.)</td> <td style="text-align: center;">Open circuit ($\infty\Omega$)</td> </tr> </table>	Rated input	W	163	Operation method		The heater is energized while defrosting. (Defrosting is finished when the evaporator is $14 \pm 1.5^{\circ}\text{C}$ or more)	Normal	Abnormal (faulty)	325Ω (Approx.)	Open circuit ($\infty\Omega$)	At the drip tray under the evaporator of the freezer compartment.
Rated input	W	163										
Operation method		The heater is energized while defrosting. (Defrosting is finished when the evaporator is $14 \pm 1.5^{\circ}\text{C}$ or more)										
Normal	Abnormal (faulty)											
325Ω (Approx.)	Open circuit ($\infty\Omega$)											
Vegetable compartment heater 1	<p>Measure the resistance with a tester. (Ambient temperature : Room temperature)</p>  <table border="1" style="width: 100%; margin-top: 10px;"> <tr> <td style="width: 50%; text-align: center;">Normal</td> <td style="width: 50%; text-align: center;">Abnormal (faulty)</td> </tr> <tr> <td style="text-align: center;">$5.9\text{k}\Omega$ (Approx.)</td> <td style="text-align: center;">Open circuit ($\infty\Omega$)</td> </tr> </table> <table border="1" style="width: 100%; margin-top: 10px;"> <tr> <td style="width: 30%;">Operation method</td> <td>The heater is turned on when vegetable compartment thermistor has reached a lower temperature than the set temperature for vegetable compartment.</td> </tr> </table>	Normal	Abnormal (faulty)	$5.9\text{k}\Omega$ (Approx.)	Open circuit ($\infty\Omega$)	Operation method	The heater is turned on when vegetable compartment thermistor has reached a lower temperature than the set temperature for vegetable compartment.	In the fan grille at the back of vegetable compartment.				
Normal	Abnormal (faulty)											
$5.9\text{k}\Omega$ (Approx.)	Open circuit ($\infty\Omega$)											
Operation method	The heater is turned on when vegetable compartment thermistor has reached a lower temperature than the set temperature for vegetable compartment.											
Vegetable compartment heater 2	<p>Measure the resistance with a tester. (Ambient temperature : Room temperature)</p>  <table border="1" style="width: 100%; margin-top: 10px;"> <tr> <td style="width: 50%; text-align: center;">Normal</td> <td style="width: 50%; text-align: center;">Abnormal (faulty)</td> </tr> <tr> <td style="text-align: center;">$5.9\text{k}\Omega$ (Approx.)</td> <td style="text-align: center;">Open circuit ($\infty\Omega$)</td> </tr> </table> <table border="1" style="width: 100%; margin-top: 10px;"> <tr> <td style="width: 30%;">Operation method</td> <td>The heater is turned on when vegetable compartment thermistor has reached a lower temperature than the set temperature for vegetable compartment.</td> </tr> </table>	Normal	Abnormal (faulty)	$5.9\text{k}\Omega$ (Approx.)	Open circuit ($\infty\Omega$)	Operation method	The heater is turned on when vegetable compartment thermistor has reached a lower temperature than the set temperature for vegetable compartment.	In partition V/F.				
Normal	Abnormal (faulty)											
$5.9\text{k}\Omega$ (Approx.)	Open circuit ($\infty\Omega$)											
Operation method	The heater is turned on when vegetable compartment thermistor has reached a lower temperature than the set temperature for vegetable compartment.											
Water pipe heater	<p>Measure the resistance with a tester. (Ambient temperature : Room temperature)</p>  <table border="1" style="width: 100%; margin-top: 10px;"> <tr> <td style="width: 50%; text-align: center;">Normal</td> <td style="width: 50%; text-align: center;">Abnormal (faulty)</td> </tr> <tr> <td style="text-align: center;">$6.6\text{k}\Omega$ (Approx.)</td> <td style="text-align: center;">Open circuit ($\infty\Omega$)</td> </tr> </table> <table border="1" style="width: 100%; margin-top: 10px;"> <tr> <td style="width: 30%;">Operation method</td> <td>When ice-making thermistor has reached approx. 10°C or below, the heater is turned on with energizing rate adjusted by the set temperature of slide compartment and freezer compartment.</td> </tr> </table>	Normal	Abnormal (faulty)	$6.6\text{k}\Omega$ (Approx.)	Open circuit ($\infty\Omega$)	Operation method	When ice-making thermistor has reached approx. 10°C or below, the heater is turned on with energizing rate adjusted by the set temperature of slide compartment and freezer compartment.	Under the water tank holder.				
Normal	Abnormal (faulty)											
$6.6\text{k}\Omega$ (Approx.)	Open circuit ($\infty\Omega$)											
Operation method	When ice-making thermistor has reached approx. 10°C or below, the heater is turned on with energizing rate adjusted by the set temperature of slide compartment and freezer compartment.											

Components/ Part Name	Check Method and Criterion	Parts Mounted Position						
Divider heater (I/S)	<p>Measure the resistance with a tester. (Ambient temperature : Room temperature)</p>  <table border="1" data-bbox="791 427 1278 533"> <tr> <td>Normal</td> <td>Abnormal (faulty)</td> </tr> <tr> <td>9.6kΩ (Approx.)</td> <td>Open circuit (∞Ω)</td> </tr> </table> <table border="1" data-bbox="389 600 1278 741"> <tr> <td>Operation method</td> <td>While compressor is operating, the heater is turned on. When compressor stops, the heater is suspended for the first 20 minutes and then reactivated.</td> </tr> </table>	Normal	Abnormal (faulty)	9.6kΩ (Approx.)	Open circuit (∞Ω)	Operation method	While compressor is operating, the heater is turned on. When compressor stops, the heater is suspended for the first 20 minutes and then reactivated.	In partition I/S.
Normal	Abnormal (faulty)							
9.6kΩ (Approx.)	Open circuit (∞Ω)							
Operation method	While compressor is operating, the heater is turned on. When compressor stops, the heater is suspended for the first 20 minutes and then reactivated.							
Rotational heater board	<p>Measure the resistance with a tester. (Ambient temperature : Room temperature)</p>  <table border="1" data-bbox="791 891 1278 996"> <tr> <td>Normal</td> <td>Abnormal (faulty)</td> </tr> <tr> <td>6.6kΩ (Approx.)</td> <td>Open circuit (∞Ω)</td> </tr> </table> <table border="1" data-bbox="389 1064 1278 1196"> <tr> <td>Operation method</td> <td>While compressor is operating, the heater is turned on. When compressor stops, the heater is suspended for the first 20 minutes and then reactivated.</td> </tr> </table>	Normal	Abnormal (faulty)	6.6kΩ (Approx.)	Open circuit (∞Ω)	Operation method	While compressor is operating, the heater is turned on. When compressor stops, the heater is suspended for the first 20 minutes and then reactivated.	In the rotational heater board of refrigerator compartment.
Normal	Abnormal (faulty)							
6.6kΩ (Approx.)	Open circuit (∞Ω)							
Operation method	While compressor is operating, the heater is turned on. When compressor stops, the heater is suspended for the first 20 minutes and then reactivated.							
Ice making tray heater	<p>Measure the resistance with a tester. (Ambient temperature : Room temperature)</p>  <table border="1" data-bbox="791 1373 1278 1478"> <tr> <td>Normal</td> <td>Abnormal (faulty)</td> </tr> <tr> <td>4.8kΩ (Approx.)</td> <td>Open circuit (∞Ω)</td> </tr> </table> <table border="1" data-bbox="389 1545 1278 1677"> <tr> <td>Operation method</td> <td>During CRYSTAL ICE mode (The heater is turned on 10 minutes after water is supplied, until 5-6 hours.)</td> </tr> </table>	Normal	Abnormal (faulty)	4.8kΩ (Approx.)	Open circuit (∞Ω)	Operation method	During CRYSTAL ICE mode (The heater is turned on 10 minutes after water is supplied, until 5-6 hours.)	Lower part of ice tray
Normal	Abnormal (faulty)							
4.8kΩ (Approx.)	Open circuit (∞Ω)							
Operation method	During CRYSTAL ICE mode (The heater is turned on 10 minutes after water is supplied, until 5-6 hours.)							




Components/ Part Name	Check Method and Criterion	Parts Mounted Position						
Thermistor	<p>Measure the resistance with a tester according to the following graph. (Thermistor resistance values against temperature)</p> <ul style="list-style-type: none"> •Resistance measured under the ambient temperature from -50°C to +50°C 1. 200Ω to 500kΩNormal 2. Out of the above rangeAbnormal <div style="display: flex; justify-content: space-between;"> <div data-bbox="288 499 766 1126"> </div> <div data-bbox="766 499 1238 1283"> <p>Thermistor Check Procedure</p> <ul style="list-style-type: none"> •Thermistor resistance value will vary with the change of temperature. •Take the temperature around the thermistor, and then measure thermistor resistance using a tester. The relation between resistance and temperature is as shown on the left side. <div style="border: 1px solid black; border-radius: 15px; padding: 5px; text-align: center; margin: 10px 0;"> Troubleshooting with self-check </div> <p>(1) If the self-check indicates the abnormality of thermistor when the power is turned on, measure the resistance of the thermistor.</p> <ul style="list-style-type: none"> •If there is a short circuit in the thermistor, there may be a defect in the contact of the connector or the element of the thermistor. <p>(2) When the self-check indicates the abnormality of thermistor a few seconds after the power is turned on, check the contact of the connector.</p> </div> </div>	<p>Defrost thermistor Evaporator</p> <p>Ice making thermistor, Versa compartment thermistor, Vegetable compartment thermistor and Freezer compartment thermistor In the fan grille of each compartments.</p> <p>Ice making tray thermistor In the ice making compartment.</p> <p>Outside air thermistor In the operation P.C. board.</p>						
Three-way valve	<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> </div> <div style="flex: 1;"> </div> <div style="flex: 2;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <td style="width: 50%;">Model</td> <td style="width: 50%;">NSCE001DC1</td> </tr> <tr> <td>Normal</td> <td>Abnormal</td> </tr> <tr> <td>54~56Ω (Gray [common]—\bar{A}/ A/ \bar{B}/ B each phase)</td> <td>Open ($\infty\Omega$) or short circuit (0Ω)</td> </tr> </table> </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px; text-align: center;"> Check the operation of three-way valve </div> <p>Check the operation by following either (1) or (2) below. When a popping sound is heard 1 to 25 times, it is considered that the valve is operating normally. The sound is clearly heard around the back of the product.</p> <p>(1) Reset the power supply. Check the operation right after this.</p> <p>(2) Ice making test. Check the operation right after the test is over.</p>	Model	NSCE001DC1	Normal	Abnormal	54~56Ω (Gray [common]— \bar{A} / A/ \bar{B} / B each phase)	Open ($\infty\Omega$) or short circuit (0Ω)	<p>In the machine chamber at the rear side of the frame.</p>
Model	NSCE001DC1							
Normal	Abnormal							
54~56Ω (Gray [common]— \bar{A} / A/ \bar{B} / B each phase)	Open ($\infty\Omega$) or short circuit (0Ω)							




Components/ Part Name	Check Method and Criterion	Parts Mounted Position						
Vegetable compartment LED (12V DC)	<table border="1"> <tr> <td data-bbox="389 315 587 472">Normal condition</td> <td data-bbox="587 315 1278 472"> <ul style="list-style-type: none"> •The pointer of the tester equipped with a diode range shakes when measuring the resistance between 4-pin connector No.3(-) and No.4(+). •Use a tester equipped with a diode range () for judgement. </td> </tr> <tr> <td data-bbox="389 472 587 546">Timing in making contact</td> <td data-bbox="587 472 1278 546">Electricity is supplied all the time.</td> </tr> <tr> <td data-bbox="389 546 587 725">Abnormal condition</td> <td data-bbox="587 546 1278 725"> <ul style="list-style-type: none"> •The pointer of the tester equipped with a diode range does not shake when measuring the resistance between 4-pin connector No.3(-) and No.4(+). •Make sure that the pointer of the tester does not shake even if the polarities are reversed. •Resistance: Short-circuited (0Ω) </td> </tr> </table> <p data-bbox="389 741 1141 770">LED shown in the figure on the right turns orange in the above timing.</p> <div data-bbox="379 792 1305 824" style="border: 1px solid black; padding: 2px;"> <p>Note: LED cannot be replaced individually because it is combined with the fan grille.</p> </div> <div data-bbox="459 853 1236 1055">  <p data-bbox="758 862 986 952">Use a tester equipped with a diode range ().</p> </div>	Normal condition	<ul style="list-style-type: none"> •The pointer of the tester equipped with a diode range shakes when measuring the resistance between 4-pin connector No.3(-) and No.4(+). •Use a tester equipped with a diode range () for judgement. 	Timing in making contact	Electricity is supplied all the time.	Abnormal condition	<ul style="list-style-type: none"> •The pointer of the tester equipped with a diode range does not shake when measuring the resistance between 4-pin connector No.3(-) and No.4(+). •Make sure that the pointer of the tester does not shake even if the polarities are reversed. •Resistance: Short-circuited (0Ω) 	In the fan grille.
Normal condition	<ul style="list-style-type: none"> •The pointer of the tester equipped with a diode range shakes when measuring the resistance between 4-pin connector No.3(-) and No.4(+). •Use a tester equipped with a diode range () for judgement. 							
Timing in making contact	Electricity is supplied all the time.							
Abnormal condition	<ul style="list-style-type: none"> •The pointer of the tester equipped with a diode range does not shake when measuring the resistance between 4-pin connector No.3(-) and No.4(+). •Make sure that the pointer of the tester does not shake even if the polarities are reversed. •Resistance: Short-circuited (0Ω) 							
LED for bacteria removal from water tank (12V DC)	<table border="1"> <tr> <td data-bbox="389 1122 587 1234">Timing in making contact</td> <td data-bbox="587 1122 1278 1234"> <ul style="list-style-type: none"> •After water is supplied to the ice tray. •After the ice level sensor lever detects that ice storage becomes full. •While the door is kept open for maximum of 5 minutes. </td> </tr> <tr> <td data-bbox="389 1234 587 1330">Abnormal condition</td> <td data-bbox="587 1234 1278 1330"> When the door is opened, LED goes out within 5 minutes. *Make sure if the connector is securely connected. </td> </tr> </table> <div data-bbox="459 1357 1268 1469">  <div data-bbox="678 1400 1268 1469" style="border: 1px solid black; padding: 5px;"> <p>Note: LED cannot be replaced individually because it is embedded in the tank holder.</p> </div> </div>	Timing in making contact	<ul style="list-style-type: none"> •After water is supplied to the ice tray. •After the ice level sensor lever detects that ice storage becomes full. •While the door is kept open for maximum of 5 minutes. 	Abnormal condition	When the door is opened, LED goes out within 5 minutes. *Make sure if the connector is securely connected.	On the external surface of the tank holder.		
Timing in making contact	<ul style="list-style-type: none"> •After water is supplied to the ice tray. •After the ice level sensor lever detects that ice storage becomes full. •While the door is kept open for maximum of 5 minutes. 							
Abnormal condition	When the door is opened, LED goes out within 5 minutes. *Make sure if the connector is securely connected.							

6-7 TEST POINT DIAGRAM OF FILTER BOARD MR-G50J-NZ



6-8 TEST POINT DIAGRAM OF CONTROL BOARD MR-G50J-NZ



Compressor
3 W phase
3 V phase
1 U phase

DC +5V
(Inverter circuit)

DNG
DC280 ~ 330V

DC+12 ~ 20V
(Inverter circuit)

CN2A
7 } AC
5 } 230V
3 Defrost
heater
1 Refrigerator
compartment

Compulsory
defrosting by
short circuit

DC+5V
(Refrige-
rator
control
circuit)

DC+12
~ 13V
(Refrige-
rator
control
circuit)

CN3A
1 Ice tray heater
3 Water pipe heater
5 Divider heater (I/S)
7 Vegetable compartment heater 1, 2
9
11 Rotational heater board


CN9D
1
2
3
4
5
6
7
8
9
10
11
12
LED for bacteria removal from water tank
Power supply of three-way valve
Electromagnetic three-way valve
Damper for ice making
compartment / versa compartment

CN4D
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
Damper for freezer
compartment
Damper for refrigerator
compartment / slide compartment
Damper for freezer
compartment
Machine chamber fan motor (+)
Refrigerator fan motor FG signal
Machine chamber fan motor FG signal
Machine chamber fan motor FG signal
Fan motor +
Damper for refrigerator
compartment / slide compartment






CN8K
1
2
3
4
5
6
7
8
Ice maker position switch
Water pump -
Ice maker (reverse)
Ice maker (rotation)
Reception of operation panel data
Power supply to operation panel data
GND

CN7S
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
Vegetable compartment LED
Door switch input
Freezer compartment thermistor
Ice maker compartment thermistor
Vegetable compartment thermistor
Versa compartment thermistor
Slide chilled compartment thermistor
Defrost thermistor
Ice making tray thermistor
Ice making tray thermistor
Refrigerator compartment thermistor
5V com

MR-G50J-NZ



MR-G50J-NZ**Plug out before work!!****Check the automatic ice-maker pressing ice making stop switch.****In assembling & disassembling parts seven kinds of screws and rivets are used. Do not mistake to use them.**

OPERATING PROCEDURE	PHOTOS
<p>1. Elect cover → Control board</p> <p>(1) Remove 5 screws fixing the elect cover and the rivet (E) on the upper rear side of the refrigerator. (See photo 1)</p> <p>Control board</p> <p>(2) Disconnect the connector to remove the control board.</p> <p>Caution on assembly</p> <p>Firmly connect the lead wires and the connector. Ensure the wires are not pinched.</p>	<p>Photo 1</p> 
<p>2. Parts inside the refrigerator compartment: Vertical partition → Right rail of the slide compartment → Left rail of the slide compartment → Room light cover → Control panel (Upper/ Lower), Duct R (Upper/ Lower)</p> <p>(1) Remove the three way flexishelf, slide chilled case, and height adjustable shelf, two way flexishelf from the refrigerator compartment.</p> <p>Vertical partition</p> <p>① Remove the small item case and the slide chilled case. ② Pull out the ceiling by unhooking the front catches on both sides. ③ Remove the slide chilled case lid. ④ Remove the vertical partition.</p>  <p>Right rail of the slide compartment</p> <p>(2) Slide the right rail out toward you. (See photo 2)</p> <p>Left rail of the slide compartment</p> <p>(3) Remove screw (G) (one screws), and slide the left rail out toward you. (See photo 3)</p> <p>Room light cover</p> <p>① Push up the lower catch, and pull the room light cover toward you. ② Detach two upper catches to take out the cover. (See photo 4)</p>	<p>Photo 2</p>  <p>Photo 3</p>  <p>Photo 4</p> 



OPERATING PROCEDURE

Control panel (upper/ lower) Duct R (upper/ lower)

(4) Remove rivet ⑤, and pull out the mirror hinge on the lower left of the control panel to remove the connector. (See photo 5)

(5) Remove rivet ⑥ (two rivets) in the upper left and right side, screw ④ (two screws) in the lower left and right side, and rivet ⑦ (two rivets) in the lower left and right side. Detach catches (seven places). (See photo 5)

(6) Detach catches (six places) on control panel (upper/ lower) and then duct R (upper/ lower).


* Control panel can be divided into the upper and lower part by detaching catches (three places) on control panel (upper/ lower)

Control panel assembly

(The assembly consists of the following: Control panel [upper/ lower], motor damper for refrigerator compartment / slide chilled compartment, refrigerator compartment thermistor, slide chilled compartment thermistor, room light socket, refrigerator compartment room light, and duct R [upper/ lower]).

Caution on assembly

To prevent poor contact of connectors, connect them properly. Fix the control panel by inserting the lower catches (two places) into the floor of refrigerator compartment.



3. Parts inside the ice making compartment, versa compartment, vegetable compartment, and freezer compartment → Partition I/ S → Partition I/ S/ V → Cover (IM) → Automatic Ice maker assembly → Cover (lower) → Partition V/ F → Connector cover (right/ left) → Fan grille → Defrost heater, Drip tray, DEF thermistor

(1) Remove interior parts out of ice making compartment, versa compartment, vegetable compartment, and freezer compartment.

(2) To detach them, pull out the doors of ice making compartment, versa compartment, vegetable compartment, and freezer compartment.

Partition I/ S

(3) Remove rivet ⑤ (one rivet), partition cover, and a connector. Remove screw ③ (two screws) at the front side of refrigerator and four rollers to pull out the partition. (See photo 6)

Caution on assembly

Push up the lead wires so that they will not rub partition I/ S.

Partition I/ S/ V




(4) Remove screw ④ (two screws) at the front of refrigerator. Remove screw ④ (one screw each) and screw ③ (one screw each) at the right and left side of inner wall. Then lift up the partition. (See photo 7)

Cover (IM)

(5) Remove 2 rivets ⑤ and 3 catches in order to detach the cover. (See photo 8)

Automatic ice maker assembly

(6) Pressing a catch upward, and pull Automatic Ice maker assembly to the right side. (See photo 8)



OPERATING PROCEDURE

Cover (lower)

(7) Remove rivet ⑤ (one rivet) to detach the cover (See photo 10)

Partition V/ F

(8) Remove screw ④ (four screws) on inner wall and screw ④ (two screws) at the front.
Detach three connectors and lift up the partition. (See photo 9)

Connector cover (right/ left)

(9) To detach connector cover, remove rivet ⑤ (two rivets each) and catches (two places).
(See photo 10)

(10) Detach the connector.

Fan grille

(11) To detach fan grille, remove screw ⑥ (two screws) of right and left side and remove upper catches (three places).

* Fan grille consists of the following: motor dampers (for ice-making compartment/ versa compartment, and freezer compartment), refrigerator fan motor, fan, thermal fuse, vegetable compartment heater 1, four thermistors, vegetable compartment LED.

(See photo 10)

Defrost heater , Drip tray

(12) To pull out defrost heater, remove the tape fixing lead wires and push up the catches of evaporator support.
Remove heater roof out of defrost heater.
To detach drip tray, remove aluminum tape first.
(See figure 1)

Defrost thermistor (DEF thermistor)

(13) Cut the binder and disconnect the connector to remove the DEF thermistor and the thermal fuse. (See photo 11)

Caution on assembly

Attach defrost heater in place and loosen the lead wires in order to prevent water from entering the glass tube.
Attach the drip tray securely to the lower parts.
Attach the DEF thermistor in place. (If they are attached out of place, thermal characteristics will go wrong.)
Attach the lead wires to the fixture.

PHOTOS

Photo 9





Photo 10



Fan grille

(Fan grille consists of the following: motor dampers (for ice making compartment / versa compartment, and freezer compartment), refrigerator fan motor, fan, thermal fuse, vegetable compartment heater 1 four thermistors, vegetable compartment LED).

Figure 1





Photo 11





OPERATING PROCEDURE

4. Parts inside the refrigerator compartment → Left rail of the slide compartment → Parts inside the ice making compartment → Ice making compartment door → Tank holder → Door switch

(1) Remove the parts inside the refrigerator compartment.
(See procedure [2])

(2) Remove the left rail of the slide compartment.
(See procedure [2])

(3) Remove the parts inside the ice making compartment.
(See procedure [3])

(4) Remove the ice making compartment door.

Tank holder

(5) Remove a screw on the side of the refrigerator compartment.
(6) Remove label and screw ④ (two screws). Pull the tank window.
(7) Loosen screw ④ (three screws) halfway on the side of the ice making compartment. Put a screwdriver on the head of each screw and top the bottom side of the holder softly to detach it.
(See photo 12)

(8) Lift up the tank holder from the refrigerator compartment to remove it.

Note:

① Put the lead wires in place so that they do not get caught in water supply channel.
② Put the tank holder in place so that the water does not leak from it.

Door switch

(9) Insert a minus screwdriver between switch and body to remove the door switch.

5. Parts inside the versa compartment → Ceiling of versa compartment



(1) Take out interior parts of versa compartment.
(2) Lift up and pull out the versa-compartment door.

Ceiling of versa compartment






(3) To detach the ceiling, remove rivet ⑤ (three rivets) and pull down the ceiling.
(See photo 13)

Caution on assembly

① Be sure that all the parts are fitted securely in place.





OPERATING PROCEDURE	PHOTOS
<p>6. Operation panel</p> <p>How to remove</p> <p>(1)Slide the operation panel in the direction of the arrows, unit it stops. (See figure 3.)</p> <p>(2)Pull out the operation panel as shown in a figure 4. (See figure 4.)</p> <p>Note :</p> <p>① Please pull it out carefully because it is still wired to the body.</p> <p>(3)Take out the panel by detaching the connector of lead wires from the body. (See figure 5.)</p> <p>Note :</p> <p>① If the horizontal slide is hard to remove with hands, put plate on the right edge of the panel (please put protective object such as tapes on the area of contact on the door panel and the operation panel), and gently tap it in the sliding direction. (See figure 3.)</p>	<p><u>Figure 3</u></p>  <p><u>Figure 4</u></p>  <p><u>Figure 5</u></p> 
<p>7. Rotational heater board</p> <p>(1)Remove four fixing screws to remove the rotational heater board. (See photo 14)</p> <p>(2)Remove a screw on the wiring cover and disconnect the connector in the cover. (See photo 14)</p> <p>Caution on assembly</p> <p>When raising the rotational heater board, replace the rotational heater board as it was. if the refrigerator door is closed with the board raised, the rotational heater board may hit against the left door of refrigerator and be damaged.</p> <p>Though heater preventing dewdrop may make rotational heater board hot, it does not affect food inside.</p> <p>Refer to right figure when installing the rotational heater board. (See figure 6)</p> <ul style="list-style-type: none"> ●Loosen the fixing screw and adjust a vertical (upper and lower) motion. ●After assembling, make sure that the rotational heater board fits the guide properly and works properly. 	<p>Photo 14</p>  <p><u>Figure 6</u></p> 

OPERATING PROCEDURE

8. Compressor cover → machine chamber fan motor

(1) Remove 7 screws for compressor cover at the back of the refrigerator.


Machine chamber fan motor

(2) Remove screw one fixing screw of bellmouth and connector. Then pull out the bellmouth.

(3) Pull out the fan from the fan motor.

(4) Remove one lid-fixing screws to take out the fan motor.

Attach U washer as the figure shown below.



Piping connection of three-way valve





Figure 7

* Note 1: Form the pipe so that it can be slanted toward the upper right. (Approx. 15 degrees).



Door adjustment

<Adjusting refrigerator compartment doors>




• Common elements


First, check the installation condition.

- ① If the adjustment bolt is not in contact with the floor, lower the bolt, and adjust it so that the caster is slightly above the floor.
- ② When the refrigerator is installed in the corner of the room, the bolt of the refrigerator may sink into the floor and cause the refrigerator to tilt. It is recommended to make adjustments by objects like boards beforehand.
- ③ When the refrigerator bolt is sunk into the floor, and it can be confirmed visually, prevent sinking by using objects like boards.

Note : The refrigerator weighs about 100kg, and is held by four bolts. How far each bolt sinks into the floor depends on factors such as floor pillars. Change in balance due to position of stored food (such as large or small amount of food stored in the door pockets) may also affect sinking.


<Adjusting ice making compartment and versa compartment doors>

Problem	Adjusting doors horizontally	Adjusting vertical space between doors	
		Too much space	Not enough space
	 <p>A > B (More space in outer side) ① Or A < B (More space in inner side)</p>	 <p>A > B (Too much space between the ice making compartment and versa compartment doors.) Misaligned versa compartment door ③ Misaligned ice making compartment door ④</p>	 <p>A < B (Small space between the ice making compartment and versa compartment doors.) Misaligned versa compartment door ⑤ Misaligned ice making compartment door ⑥</p>
Solution	<p>① Place spacer set under the outer roller of the tilted door (ice making compartment door in the above illustration) to adjust position.</p> <p>② Place spacer set under the inner roller of the tilted door (ice making compartment door in the above illustration) to adjust position.</p>	<p>③ Replace roller set of the right and left versa compartment doors.</p> <p>a To adjust about 0.5mm Replace with roller set C.</p> <p>b To make large adjustment Replace with roller set D.</p> <p>④ Replace lower roller set of the ice making compartment door.</p> <p>c To adjust about 0.5mm Replace with roller set A.</p> <p>d To make large adjustment Replace with roller set B.</p>	<p>③ Place roller set of the right and left versa compartment doors.</p> <p>a To adjust about 0.5mm Replace with roller set A.</p> <p>b To make large adjustment Replace with roller set B.</p> <p>⑥ Replace lower roller set of the ice making compartment door.</p> <p>c To adjust about 0.5mm Replace with roller set C.</p> <p>d To make large adjustment Replace with roller set D.</p>



Identifying roller sets (Marking)

	LH	RH
Roller set A (0.5mm to the right)	09	10
Roller set B (0.5mm to the right)	11	12
Roller set C (0.5mm to the right)	13	14
Roller set D (0.5mm to the right)	15	16

ELECTRICAL PARTS
MR-G50J-SS-NZ



Part numbers that are circled are not shown in the figures.

No.	RoHS	Part No.	Part name	Spec. or Drawing No.	MR-G50J	
					NZ	SS
					1	G
2	G	T1W 13W 339	Control board		1	
3	G	T1W 06W 312	Refrigerator compartment thermistor		1	
4	G	T1W 06W 366	Room light socket		1	
5	G	T1W 01W 360	Refrigerator compartment room light	240V,10W	1	
6	G	M20 KA3 313	Chilled compartment thermistor		1	
7	G	T1W 13W 395	Plug cord assembly		1	
8	G	M20 KA2 313	Versa compartment thermistor		1	
9	G	M20 KA7 313	Ice making compartment thermistor		1	
10	G	M20 KA0 311	Defrost thermistor		1	
11	G	T1W 06W 316	Vegetable compartment thermistor		1	
12	G	M20 KA1 313	Freezer compartment thermistor		1	
13	G	T1W 01W 469	Gear box	In the automatic ice maker	1	
14	G	M20 KA0 327	Motor (Water tank)		1	
15	G	T1W 01W 316	Ice-tray thermistor		1	
16	G	M20 KW0 656	Bell mouth		1	
17	G	M20 KA0 325	Machine chamber fan motor	UDQM004B3	1	
18	G	T1W 02W 339	Filter board		1	
19	G	T1W 06W 338	Operation P.C. board	With operation P.C. board box	1	
20	G	T1W 06W 388	Door switch		1	
21	G	T1W 06W 537	Heater roof		1	
22	G	T1W 13W 392	Defrost heater	230V,163W / Deodorizing function not equipped	1	
23	G	M20 KG0 536	Drip tray	Equipped with fixing tape	1	
24	G	M20 KA0 340	Motor protector	MM3-71CCV	1	
25	G	M20 KL0 341	Terminal cover		1	
26	G	M20 KW1 321	Fan		1	
27	G	M20 KW0 329	Bush		2	
28	G	T1W 01W 304	Lead wire assembly	Lead wire of compressor	1	
29	G	M20 KG0 304	Lead wire assembly	Lead wire of fan motor in machine room	1	

DOOR PARTS
MR-G50J-SS-NZ

Abbreviation

R/ L	Refrigerator compartment (Left)	F	Freezer compartment
I	Ice making compartment	R/ R	Refrigerator compartment (Right)
V	Vegetable compartment	S	Versa compartment




Part numbers that are circled are not shown in the figures.

No.	RoHS	Part No.	Part name	Spec. or Drawing No.	MR-G50J
					NZ
					SS
1	G	T1W 01W 701	Hinge assembly (Left/ Upper)		1
2	G	T1W 13W 009	Outer door panel (R/L)	With hinge assembly (Left/ Upper), *1	1
3	G	T1W 07W 852	Operation panel		1
4	G	M20 KL1 026	Door closer (Left)		1
5	G	M20 KW4 747	Door stopper (Left)		1
6	G	T1W 13W 004	Outer door panel (I)	Without gasket	1
7	G	T1W 13W 002	Outer door panel (V)	Without gasket	1
8	G	T1W 13W 001	Outer door panel (F)	Without gasket	1
9	G	M20 KA1 701	Hinge assembly (Right/ Upper)		1
10	G	T1W 13W 000	Outer door panel (R/R)	Without gasket, With hinge assembly (Right/ Upper)	1
11	G	M20 KE5 026	Door closer (Right)		1
12	G	M20 KW8 745	Door stopper (Right)		1
13	G	T1W 13W 006	Outer door panel (S)	Without gasket	1
14	G	M20 KG0 120	Free pocket (L)		2
15	G	M20 KG1 110	Door gasket (R/R)		1
16	G	M20 KG0 124	Bottle pocket (L)		1
17	G	M20 KG0 139	Tube stand		1
18	G	M20 KL0 930	Frame screw	6 pieces included	4
19	G	M20 KG0 113	Door gasket (S)		1
20	G	M20 KG1 155	Frame (S)		1
21	G	M20 KG0 151	Frame (V)		1
22	G	M20 KG0 157	Frame (F)		1
23	G	T1W 06W 050	Rotational heater board		1
24	G	M20 KG2 110	Door gasket (R/L)		1
25	G	M20 KG0 118	Free pocket (M)		2
26	G	M20 KG0 123	Bottle pocket (S)		1
27	G	M20 KG0 114	Door gasket (I)		1
28	G	M20 KG1 154	Frame (I)		1
29	G	M20 KG0 112	Door gasket (V)		1
30	G	M20 KG0 112	Door gasket (F)		1
31	G	M20 KG0 108	Packing (F)	For interior board of freezer compartment door	1
32	G	M20 KL0 607	Spring (Rotational heater board)		1
33	G	M20 KW0 717	Upper hinge assembly (Rotational heater board)		1
34	G	T1W 06W 715	Lower hinge assembly (Rotational heater board)	With spring	1

*1: Without gasket, Operation panel, Operation P.C. board, Rotational heater board.

BODY PARTS
MR-G50J-SS-NZ



Abbreviation

R.V.	Between refrigerator compartment and vegetable compartment
I.M.	Ice maker
I.S.	Between ice making compartment and versa compartment
V.F.	Between vegetable compartment and freezer compartment
I.S.V	Between ice making compartment, versa compartment and vegetable compartment

Part numbers that are circled are not shown in the figures.

No.	RoHS	Part No.	Part name	Spec. or Drawing No.	MR-G50J	
					NZ	SS
1	G	T1W 06W 858	Control panel assembly	*1		1
2	G	M20 KL0 705	Hinge cover (Left)			1
3	G	T1W 06W 863	Left rail of slide compartment			1
4	G	T1W 06W 663	Fan grille	*2		1
5	G	T1W 06W 808	Connector cover (Fan grille)	Three types; One cover each		1
6	G	M20 KA0 525	Water pipe			1
7	G	M20 KA1 702	Hinge assembly (Left/ Lower)			1
8	G	T1W 01W 521	Water tank holder	*3		1
9	G	T1W 01W 350	Automatic ice maker assembly	With ice making tray heater		1
10	G	M20 KL1 442	Cover I.M. assembly			1
11	G	T1W 06W 652	Compressor cover			1
12	G	M20 KA0 794	Caster set			2
13	G	M20 KW0 709	Screw label			2
14	G	M20 KA0 795	Caster assembly			2
15	G	M20 KA0 460	Adjustment bolt			2
16	G	M20 KW0 707	Hinge cover (Right)			1
17	G	M20 KW1 835	Guide			1
18	G	M20 KK4 470	Room light cover			1
19	G	M20 KL0 864	Right rail of slide compartment			1
20	G	M20 KL0 802	Vertical partition			1
21	G	M20 KL0 503	Tank pipe			1
22	G	M20 KG0 802	Ceiling of versa compartment			1
23	G	M20 KW3 442	Filter cover			1
24	G	M20 KW0 526	Light-type bacteria removing filter	Combined with photocatalyst		1
25	G	M20 KL0 531	Water supply port cap			1
26	G	M20 KW0 519	Water pump			1
27	G	M20 KA0 702	Hinge assembly (Right/ Lower)			1
28	G	M20 KL0 527	Water tank cover			1
29	G	M20 KL0 106	Packing (Water tank cover)			1
30	G	M20 KL0 520	Water tank assembly	*4		1
31	G	T1W 01W 524	Tank window			1
32	G	M20 KL2 442	Partition cover			1
33	G	T1W 01W 802	Partition (I.S)	With heater board		1
34	G	M20 KL0 803	Roller assembly	A set for both sides		2
35	G	M20 KG1 846	Partition (I.S.V)			1
36	G	M20 KG1 798	Bearing			4
37	G	T1W 06W 846	Partition (V.F)	With vegetable compartment heater 2		1
38	G	T1W 07W 730	Toe grille			1
39	G	M20 KG0 712	Spacer set	For difference adjustment of the I-door and the S-door		2
40	G	M20 KW0 805	Rivet			1
41	G	M20 KL0 442	Thermistor (I) cover	In the automatic ice maker		1
42	G	T1W 06W 107	Packing (Upper)	Compartment side (Upper part)		1
43	G	M20 KG0 798	Bearing F/V			4

*1: With motor damper for refrigerator compartment / slide chilled compartment, refrigerator compartment thermistor, slide chilled compartment thermistor, room light socket, refrigerator compartment room light, and duct R (upper/ lower).

*2: With thermal fuse, motor dampers for ice making compartment / versa compartment, and freezer compartment / refrigerator fan motor, fan, vegetable compartment heater 1, thermistors (for versa compartment, ice making compartment, vegetable compartment, and freezer compartment), LED for vegetable compartment.


*3: With water pump motor, water pipe and LED for bacteria removal from water tank.

*4: With tank pipe, filter cover, light-type bacteria removing filter, water pump, water supply port cap, water tank cover and packing (water tank cover).

ACCESSORY AND UNIT PARTS MR-G50J-SS-NZ

Abbreviation

F	Freezer compartment	S	Versa compartment
V	Vegetable compartment		



Part numbers that are circled are not shown in the figures.

No.	RoHS	Part No.	Part name	Spec. or Drawing No.	MR-G50J	
					NZ	SS
1	G	M20 KG0 427	Two-way flexishelf (Rear)			1
2	G	M20 KG1 428	Two-way flexishelf (Front)			1
3	G	M20 KG1 423	Height adjustable shelf			1
4	G	M20 KG1 427	Three-way flexishelf (Rear)			1
5	G	M20 KG1 428	Three-way flexishelf (Front)			1
6	G	M20 KL0 122	Small item case			2
7	G	M20 KL1 115	Free egg shelf (S)			2
8	G	M20 KG0 483	Ice mat	Blue (upper mat)		1
9	G	M20 KG0 467	Ice storage bin			1
10	G	M20 KG1 483	Soundproof mat	White (lower mat)		1
11	G	M20 KW0 462	Ice server			1
12	G	M20 KG1 406	Slide case (V)			1
13	G	M20 KG1 414	Freezing case (Upper)			1
14	G	M20 KG1 451	Freezing case (Lower)			1
15	G	M20 KG0 456	Ceiling of slide compartment			1
16	G	M20 KG0 411	Slide chilled case			1
17	G	M20 KG0 418	Slide chilled case lid			1
18	G	M20 KG0 437	Aluminum tray (S)			1
19	G	M20 KG0 444	Versa case			1
20	G	M20 KG0 404	Vegetable stand			1
21	G	T1W 06W 405	Vegetable case			1
22	G	M20 KW0 435	Drain pan			1
23	G		Evaporator assembly			1
24	G		Compressor	ETI100E13DAH		1
25	G		U washer	3 washers		1
26	G		Rubber mount	Operation manual provided, 4 pieces included		1
27	G		Dryer pipe set			1
28	G		Valve coil			1
29	G		Three-way valve	With valve coil		1
30	G		Radiator plate assembly			1
(31)	G		Packing (Radiator plate)			1



HEAD OFFICE: TOKYO BLDG., 2-7-3,MARUNOUCHI,CHIYODA-KU, TOKYO100-8310,JAPAN

©Copyright 2006 MITSUBISHI ELECTRIC ENGINEERING CO.,LTD.
Distributed in Jul. 2006. No. OA090 7
Made in Japan

New publication, effective Jul. 2006
Specifications subject to change without notice.